

LEDDim Smart Pill Mini



230V, 50/60Hz, -20°C to 35°C

LEDDim App






Android OS 5.1, Ram 2.5GB mid-range CPUs<



<http://www.sg-as.no/leddim/getapp/>





iOS 9.0, iPhone 5s<



NO: Impulsbryter (valgfritt)
EN: Push button (optional)
FR: Bouton-poussoir (optionnel)
NL: Drukknop (optioneel)
DE: Druckknopf (optional)
FI: Painonappi (valinnainen)

			
Max. 200W	Max. 160W	Max. 160W	




NO: Minimum dimmenivåjustering
EN: Minimum dimming level adjustment
FR: Réglage du niveau de gradation minimal
NL: Regelbaar niveau van minimale dimmingsgraad
DE: Anpassung der minimalen Dimmstufe
FI: Minimi himmennystaso



Reset



NO: Kan kun installeres av en registrert installasjonsvirksomhet.
EN: Only to be installed by an authorized electrician.
FR: Doit être installé par un électricien autorisé.
NL: Mag alleen geïnstalleerd worden door een bevoegde elektricien.
DE: Dieses Produkt darf nur durch autorisiertes Personal (z. B. Elektro-Installateur) angeschlossen und in Betrieb genommen werden.
FI: Asentaa saa vain valtuutettu sähköasentaja



NO: Skru av strømmen før montering.
EN: Turn off power before installing.
FR: Couper le courant avant l'installation.
NL: Stroom uitschakelen voor u het toestel installeert.
DE: Vor Installationsarbeiten den Strom abschalten.
FI: Sammuta virta ennen kytkemistä



NORWAY SG Armaturen AS
Tlf:+47 37 50 03 00
firmapost@sg-as.no
www.sg-as.no

SWEDEN SG Armaturen AB
Tel: +46 31 81 71 10
info@sg-ab.se
www.sg-ab.se

FRANCE SG Lighting SA/NV
Tel: +33(0) 4 94 93 00 00
info.france@sglighting.fr
www.sglighting.net

GERMANY SG Leuchten GmbH
Tel: +49 40 23 99 44 59
info@sg-leuchten.de
www.sg-leuchten.de

DENMARK SG Armaturen A/S
Tel: +45 70 70 72 13
info@sg-as.dk
www.sg-as.dk

FINLAND SG Armaturen Oy
info@sg-oy.fi
www.sg-oy.fi





BENELUX SG Lighting SA/NV
Tel: +32(0) 15 20 72 71
info.benelux@sglighting.net
www.sglighting.net

INTERNATIONAL SG Lighting Co Ltd.
Tel: +86 769 88 49 20 88
cindy@sgdgc.com
www.sg-as.com




iOS LEDDim Guide







1. REGISTER create account




2. LOCATION create location




3. MANAGE DEVICE add dimmers



4. GROUP create group



5. LOCATION Share location



LEDDIM Guide




<http://www.sg-as.no/leddim/>


Android LEDDim Guide




1. REGISTER create account




2. LOCATION create location



3. MANAGE DEVICE add dimmers



4. GROUP create group



5. LOCATION Share location

