









CE20-01
CE20-03

0 10 20 30 40 50 60 70 80 90 100 110 120 130 140 150 160 170 180 190 200


A

*CE20-03 only


B**C****D****E****G****B****C**





HWAT-L
HWAT-M
HWAT-R → CE25-01

Aluminium



FS-A-2X
FS-B-2X
FS-C-2X
FS-C10-2X
GM-2X
FroStop Black
FroStop Green
LC2-10-CR
FreezeGard-W32
FreezeGard-W52
R-ETL-A







HWAT-L/-M

4

4



HWAT-L/-M

Aluminium



FS-A-2X
FS-B-2X
FS-C-2X
FS-C10-2X
GM-2X

FroStop Black
FroStop Green
LC2-10-CR
FreezeGard-W32
FreezeGard-W52

HWAT-L
HWAT-M
ETL-A


5

5


150 mm

6


7




8




9



10




CE20-03 → 20




CE20-01

11→19

11



12






HWAT-L/-M

13

13



HWAT-L/-M




FS-A-2X
FS-B-2X
FS-C-2X

FS-C10-2X
GM-2X
FroStop Black


FroStop Green
HWAT-L
HWAT-M

14


40 mm




15




16




17







18




19







23




24




25




26



27





België / Belgique

Tyco Thermal Controls
Romeinse Straat 14
3001 Leuven
Tel. 016 21 35 02
Fax 016 21 36 04

Česká Republika

Tyco Thermal Controls Czech, s.r.o.
Pražská 636
252 41 Dolní Břežany
Tel. +420 241 911 911
Fax +420 241 911 100

Danmark

Tyco Thermal Controls Nordic AB
Flöjelbergsgatan 20B
SE-431 37 Mölndal
Tel. 70 11 04 00
Fax 70 11 04 01

Deutschland

Tyco Thermal Controls GmbH
Englerstraße 11
69126 Heidelberg
Tel. 0800 1818205
Fax 0800 1818204

España

Tyco Thermal Controls N.V.
Ctra. De la Coruña, km. 23,500
Edificio ECU I
28290 Las Rozas, Madrid
Tel. (34) 902 125 307
Fax (34) 91 640 29 90

France

Tyco Thermal Controls SAS
B.P. 90738
95004 Cergy-Pontoise Cedex
Tél. 0800 906045
Fax 0800 906003

Italia

Tyco Thermal Controls SPA
Centro Direzionale Milanofiori
Palazzo F1
20090 Assago, Milano
Tel. 02 5776151
Fax 02 577615528

Nederland

Tyco Thermal Controls b.v.
Van Heuven Goedhartlaan 121
1181 KK Amstelveen
Tel. 0800 0224978
Fax 0800 0224993

Norge

Tyco Thermal Controls Norway AS
Postboks 146
1441 Drøbak
Tel. 66 81 79 90
Fax 66 80 83 92

Österreich

Tyco Thermal Controls
Office Wien
Brown-Boveri Strasse 6/14
2351 Wiener Neudorf
Tel. 0 22 36 86 00 77
Fax 0 22 36 86 00 77-5

Polska

Tyco Thermal Controls Polska Sp. z o.o.
ul. Cybernetyki 19
02-677 Warszawa
Tel. +48 22 331 29 50
Fax +48 22 331 29 51

Schweiz / Suisse

Tyco Thermal Controls N.V.
Office Baar
Haldenstrasse 5
Postfach 2724
6342 Baar
Tel. 041 766 30 80
Fax 041 766 30 81

Suomi

Tyco Thermal Controls Nordic AB
Flöjelbergsgatan 20B
SE-431 37 Mölndal
Puh. 0800 11 67 99
Faksi 0800 11 86 74

Sverige

Tyco Thermal Controls Nordic AB
Flöjelbergsgatan 20B
SE-431 37 Mölndal
Tel. 020-210 100
Fax 031-335 58 99

Türkiye

SAMM Dış Ticaret A.Ş.
Yeniyol Sk. Etap İş Merkezi C Blok No: 10
Kat: 6
34722 Acıbadem - Kadıköy
İSTANBUL
Tel: +90-216-325 61 62 (Pbx)
Faks: +90-216-325 22 24

United Kingdom

Tyco Thermal Controls (UK) Ltd
3 Rutherford Road,
Stephenson Industrial Estate
Washington, Tyne & Wear
NE37 3HX
Tel. 0800 969013
Fax: 0800 968624

РОССИЯ и другие страны СНГ

ООО « Тайко Термал Контролс »
141407, Московская обл., г. Химки
ул. Панфилова, 19, 11 этаж,
Деловой Центр Кантри Парк
Тел. +7 (495) 926 18 85
Факс +7 (495) 926 18 86



Thermal Controls

www.tycothermal.com

