



GEZE DØRLUKKERE

Indstilling og justering


Afmontering dækkappe



Montering dækkappe




GEZE TS 5000




- 1 - Lukkehastighed →
- 2 - Sluttryk
- 3 - Åbningsdæmpning
- 4 - Lukkekraft

Styrke	Fløjbredde (mm)
2	op til 850
3	850 - 950
4	950 - 1100
5	1100 - 1250
6	1250 - 1400





GEZE TS 4000




- 1 - Lukkehastighed →
- 2 - Sluttryk
- 3 - Åbningsdæmpning
- 4 - Lukkekraft

Styrke	Fløjbredde (mm)
1	op til 750
2	750 - 850
3	850 - 950
4	950 - 1100
5	1100 - 1250
6	1250 - 1400




GEZE TS 3000 V





- 1 - Lukkehastighed →
- 2 - Sluttryk
- 3 - Åbningsdæmpning
- 4 - Lukkekraft


Styrke	Fløjbrede (mm)	
1	op til 750	—
2	750 - 850	2,5 omdrejninger
3	850 - 950	5 omdrejninger
4	950 - 1100	+




GEZE TS 2000 V




- 1 - Lukkehastighed →
- 2 - Sluttryk



GEZE TS 1500



- 1 - Lukkehastighed →
- 2 - Sluttryk



GEZE Danmark

Høje Taastrup Boulevard 53

DK-2630 Taastrup

Telefon: +45 46 323 324

Telefax: +45 46 323 326

Web: www.geze.dk